

Fitting Instructions #4181IS

Volkswagen Golf Mk7


Rear Control Arm Lower Inner Bushing



- Jack the vehicle up and support on jack stands;
- Remove the lower control arms;

Note: before removing the bushes, add a split spacer ring as it is shown in the picture;

- Remove original shell/bush part from the housing with the use of a hydraulic press and suitable pressing tools;
- Install the new bush as it is shown in the picture. Do not remove the split spacer ring before pressing the new bushes;
- Apply the white grease supplied to the bore of the bush and the outside of the crush tube;
- Push in the crush tube;
- Refit the control arm to the vehicle. Tighten all bolts to manufactures torque settings;
- Carry out a wheel alignment.



Note: Polyurethane bushings must be fitted to both sides of the vehicle. This kit should be installed by a Qualified Motor Mechanic.