

# Fitting Instructions #4195IS

Volkswagen Golf Mk7

*Trailing Arm Rear Bushing*



- Jack the vehicle up and support on jack stands;
- Remove the trailing arms;
- Remove original shell/bush part from the housing with the use of a hydraulic press and suitable pressing tools;
- Check the side of the trailing arms and Install the new bush as it is shown in the picture;
- Apply the white grease supplied to the bore of the bush and the outside of the crush tube;
- Push in the crush tube;
- Refit the control arm to the vehicle. Tighten all bolts to manufactures torque settings;
- Carry out a wheel alignment.



*Note:* Polyurethane bushings must be fitted to both sides of the vehicle. This kit should be installed by a Qualified Motor Mechanic.