

Fitting Instructions #3267IS

HOLDEN Commodore VN and VZ

Rear Subframe Replacement Bushes (I.R.S. only)

- Remove the Factory Bushes and Fit the New Polyurethane Bushings with reference to the diagrams below. **Note** the Position and the Direction of Installation for each bushing.

