



# All Weather Rubber Ute Mat - Type C

To suit: Hilux Extra / Double Cab Chassis

Fitting Instructions

Accessory Part No. : PZQ20 89080

Installation time: 8 min. approx.

Please Install the Rubber Ute Mat in accordance with the following instructions:

**Step 1.** Remove the Mat from the packaging and unroll it completely. To help the mat to sit flat against the tray loosely roll the mat in the opposite direction to the way it was rolled for shipment, then unroll again.

**Step 2.** If fitting to Hilux Extra Cab place Mat in tray. If fitting to Hilux Double Cab go to *Step 3*.

**Step 3.** Trim Mat along trim line as per part drawing then fit in tray

