

Fitting Instructions – Z6253

Honda Accord 2013-2018

Trailing/Control Arm Bush



Rear

Note, this instruction sheet should be used in conjunction with a workshop manual and proper safety procedures followed.

- Place the vehicle securely on a hoist or jack stands
- Remove the control arm from the vehicle
- Remove OE rubber bushes from the arm either using a press and press tools or by cutting the steel shell out (if cutting be careful not to damage the arm and clean up any damage that is done to the bore of the arm with sandpaper).
- Press the new bush into the arm using a hydraulic or arbor press until the bush has clipped onto either side of the arm as shown below.



- Grease the bore of the bush and the outside of the crush tube and then push the crush tube into the bush, the assembled bush should look as below



- The control arm can now be re-installed
- Wheel alignment after install is recommended