

Fitting Instructions

Front Lower Control Arm

Z6075

Install Guide

Application - Toyota Prado 120 Series - 05-On Toyota Hilux 4WD

Always refer to current catalogue for complete listing

1. Raise vehicle evenly and safely support.
2. Remove the wheels from vehicle.
3. Remove the two lower ball joint bolts.
4. Remove the shock absorber lower mounting bolt from the lower control arm.
5. Loosen the two inner lower control arm bolts from the vehicle.
6. While supporting the wheel hub assembly remove the two lower control arm bolts and arm from the vehicle.

- Contents** - 1 x 69238 Bushing (smaller)
- 1 x 68537 Bushing (larger)
- 1 x Steel tube 25.4x14.3x83
- 1 x Steel tube 25.4x14.3x65
- 1 x Steel tube 25.4x19.5x65
- 2 x 19mm Inside diameter washers
- 4 x 14mm Inside diameter washers
- 1 x Grease

NOTE - check camber bolt condition. If bolts are excessively rusty, you may wish to replace.

7. Apply supplied grease to bushing internal diameter and side face - supplied washers are installed on the bushing face

NOTE - select 14mm or 19mm ID steel tubes and washers for smaller bushing (depending on your vehicle bolt size)

8. Re-install lower control arm to the vehicle.
9. Re-fit road wheels and settle vehicle on the ground.
10. Carry out wheel alignment immediately after install.
11. Re-check all bolts after 100kms travelled.

