

INSTALLATION GUIDE

Front Control Arm Rear Bushing

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Application: Mercedes Vito - 2010-2014

Instructions

1. Raise vehicle evenly and safely support.
2. Remove front wheel and proceed to un-bolt control arms.
3. Once arm is removed, proceed to Press out the control arm Pin from the OE bushing and Housing (a Cold Chisel may be used to prevent slippage when pushing on control arm Pin).
4. Now the Bushing can be pressed out from the OE Housing.

*Remove any burrs from Housing and control arm Pin.

5. Press in supplied bushing into OE housing - note image below regarding bushing position.
6. Grease bushing ID with supplied grease and slide new bushing over control arm Pin.
7. Re-fit arm to vehicle - tighten bolts to Manufacturers specifications.

Press bushing in approx.
21mm



N.B: It is recommended that a licenced workshop or trades person carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above