

Install Guide

Rear Lower Wishbone Inner Eye Bushing Kit

Jeep Grand Cherokee WK2

Z7098-N
Page 1 of 2

Nolathane[®]

Note: These components must be fitted by a qualified person only, as per the manufacturers' service manual. Also, all relevant safety procedures are followed in addition to the following. Photos are an indication and may vary slightly in appearance from the actual product.

Kit Contents:

- 8 x 4978 Bush
- 4 x 24x14.3x69.5 Tube

1. Raise vehicle with a hoist for ease of installation; otherwise approved floor stands can be used.
2. Remove exhaust system up to engine pipes.
3. Remove lower shock mount bolt. (Figure 01).
4. Place adjustable stand beneath cradle and loosen cradle bolts to allow cradle to drop down. (See Figure 02).



Figure 01 – Left Rear Lower Wishbone Control Arm



Figure 02 – Cradle Bolts to be loosened.

5. Remove cradle bolts gradually on each side to loosen the coil springs.
6. Remove the cradle bolt and loosen wishbone bolts. (Note that the front bolt can only be loosened once the cradle is moved back slightly) (See Figure 03).
7. After removing wishbone bolts, the control arm will lever out of its interior mounts giving access to the inner bushes. Use appropriate tools to remove the old bushes. (See Figure 04).
8. Ensure the mounting orifice is clean of debris and burrs.
9. Fit new Control Arm Bushes '4978' into inner wishbone eyes after first lubricating the external face (which makes contact with the eye) evenly with the supplied grease.
10. Apply supplied grease evenly to external face of supplied crush tube and push into the installed bushing.
11. Place coil spring appropriately and raise cradle back into position.
12. Fasten cradle bolts and re-torque all nuts to manufacturer's specifications. (130Nm for the Nut)
13. Retighten all bolts after 1000km.

Install Guide

Rear Lower Wishbone Inner Eye Bushing Kit

Jeep Grand Cherokee WK2

Z7098-N
Page 2 of 2

Nolathane®



Figure 03 – Lowered Cradle being moved back for access to front bolt.



Figure 04 – Booker-Rod set up to remove pre-existing bushes.