

FITTING INSTRUCTION

Important notice:

This kit contains 6 x SB15 and 2 x 2375 bushes.

The 2375 bushes are designed for fitment at the lowest point on the sway bar links.

Please note the direction of the cup washers when fitted to the link pins (as per diagram).

