

Fitting Instructions

Toyota Prado 150

Rear Bump Stop

Note: Fitting instructions apply to both sides of the car on the rear differential. SuperPro must be fitted to both sides of the vehicle.

- Jack car up on hoist or jack stands.
 - Remove wheels from both sides of car.
 - Support the rear diff with long adjustable stands/under hoist stands.
 - Unbolt rear shock top mount.
 - Lower the rear axle of the car until the rear spring becomes unseated from the chassis. Be very cautious not to stretch the brake lines or ABS wiring during this process.
 - Install the bump stop in the top of the spring facing down through the spring. Refer to Figure 01.
- Note:** Bump stop **MUST** be installed in the top of the spring (larger diameter side).
- Reseat the spring on the rear differential and raise the axle until the spring is also seated on the chassis. Ensure the spring has seated correctly at both ends.
 - Reinstall the shock top mount to chassis.
 - Manufacturer's torque setting must be used on all bolts.
 - Recheck all bolts after 1000km or 1 month.



Figure 01 – Completed Installation of Bump Stop