

Install Guide

Rear Lower Shock Bushings

Suggested method for replacement below

Application - Jeep Grand Cherokee
- WK Wk2 2011 - on

(Always refer current catalogue listing)

- Raise vehicle evenly and safely support with a hoist or stands.

Never rely on a Jack only

- Proceed to remove rear wheels.

Contents - Bushings 4943 x2
- 28.5 x 16.3 x 61.5mm x2
- Grease

Note - The exhaust system will have to be dropped - to be able to lower cradle down.

- Next, loosen and remove lower shock bushing bolt.
- Place a stand (or jack with timber) under rear cradle.
- Proceed to loosen the cradle bolts - refer image on page 2.
- Place the shock out of the way using wire or cable ties.

Tip - a suggested method to remove the shock bushing is using an Air-hacksaw

Refer page 2 -



Figure 01 - Left Rear Lower Wishbone

Note: These components must be fitted by a qualified person only, as per the manufacturers service manual. Also, that all relevant safety procedures are followed in addition to above.

Install Guide

Rear Lower Shock Bushings



Figure 02 - Cradle Bolts to be loosened.

- Whilst rear frame is supported - continue to remove rear cradle bolts - to release tension on rear coils.



- Refer RH image of reciprocating saw cutting into old bushing. Careful to not damage aluminium arm.

- Press new bushings into clean control arm. A press tool kit with threaded rods will work.

- Grease bushing internal diameter and side face with supplied grease only. Re-fit arms to vehicle.

- Re-assemble vehicle - (check coil spring located properly). Test Drive.
Re-check bolts after 500kms

- A wheel alignment is recommended.



Figure 03 - Removal of Shock Eye Bush

Note: These components must be fitted by a qualified person only, as per the manufacturers service manual. Also, that all relevant safety procedures are followed in addition to above.