

# Install Guide

## IFS Front Lower Diff Support Bush Toyota Landcruiser 100 Series

**Nolathane**<sup>®</sup>

**Note:** These components must be fitted by a qualified person only, as per the manufacturers' service manual. Also, all relevant safety procedures are followed in addition to the following. Photos are an indication and may vary slightly in appearance from the actual product.

### Kit Contents:

- 1 x 3575 Bush
- 1 x 27x14.3x68.5 Steel Tube

1. Jack vehicle up and put on stands/hoist. Then use a bottle jack or similar to support the differential.
2. Undo the fasteners as marked above as marked below and remove the lower differential support arm.



3. With the use of a hydraulic press and suitable pressing tools, press out the factory rubber bush including the shell.
4. Clean and remove any burrs in the housing.
5. Press in the new polyurethane steel shell part into the housing.
6. Apply grease supplied onto the side faces of the bush and the contact area with the bush and install the arm back into the vehicle.
7. Ensure all fasteners are torque to manufacturer's specification.

