

# Install Guide

## Rear Sway Bar Link Upper Bushing

### Toyota Land Cruiser 200 Series

Z7096-N  
Page 1 of 1

**Nolathane**<sup>®</sup>

**Note:** These components must be fitted by a qualified person only, as per the manufacturers' service manual. Also, all relevant safety procedures are followed in addition to the following. Photos are an indication and may vary slightly in appearance from the actual product.

#### Kit Contents:

- 4 x 4805 Bush

Note: Polyurethane bushings must be fitted to both sides of the vehicle.

1. Jack the vehicle up and support on jack stands/hoist and remove the sway bar links.
2. Remove original upper rubber bushes from the sway bar link.
3. Apply the supplied grease on the bore surface of the new '4805' bushes and install them, as shown in the Figure 01.
4. Apply the same procedure to the other sway bar link.
5. Refit the control arms to the vehicle and tighten all bolts to manufacture's torque settings.

