

Fitting Instructions

Steering Rack Mount

Code: Z5210A

Application:

FALCON BA/BF 9/02-5/08

CONTENTS:
2X BUSHES

Always refer to current catalogue for complete application listing.

INSTRUCTIONS

1. Raise vehicle evenly and support with jack stands.
2. Remove the 2 swaybar mounting brackets, then unbolt the steering rack pinion and mounting bolts. Refer fig 1 and 2.
3. Remove the OE 2 piece rubber bush and tube from the steering rack. Refer fig 3.
4. Clean up the eyelet and OE tube and remove any dirt, oil or grease.
5. Insert new 2 piece poly bush with flat edge facing up. Refer fig 4.
6. Apply the supplied grease to the ID of the poly bush.
7. Once the steering rack is back in position, slide OE tube into ID. Refer fig 5.
8. Tighten all mounting bolts then mount swaybar brackets back in position.
9. Re check all nuts and bolts after initial 100km.



FIG1



FIG2



FIG3



FIG5



FIG4

Warning: Please drive carefully while you accustom yourself to the changed vehicle behaviour