Instruction Sheet **Rear Camber Adjusting Kit**

Suits: Subaru Impreza GH 9/07-on

N.B: This instruction sheet should be used in conjunction with workshop manual

Contents:

4 x half-bushes, wide shoulder (rear bush) 4 x half-bushes, narrow shoulder (front bush) 2 x eccentric crush tubes, long (rear bush) 2 x eccentric crush tubes, short (front bush) 4 x bolts, long 4 x bolts, short 4 x nuts 8 x spring washers 1 x grease sachet



Z5126



Installation guide:

Please read complete installation guide and check kit components prior to fitment. These instructions are to be used in conjunction with workshop manual, and it is recommended that all work be carried out by a qualified technician.

- Measure wheel alignment settings prior to any disassembly. 1.
- 2. Raise the vehicle with a hoist / lift or alternatively raise and support on safety chassis stands, and remove rear wheels.
- 3 Disconnect outer ball-joints and remove upper control arms.
- Remove original bushes from control arms, clean any debris from 4 hole. Smear a light film of grease on bushes and fit to control arms. Fig 2 - left control arm with new bushes. Apply grease inside the bushes and press crush tubes inside. Note: Bush with wider shoulder and longer crush tube must be fitted to the rear mount, as shown in Fig 2.
- 5. Reconnect control arm to subframe as shown in Fig 3 and 4.WASHER Ensure that long bolt (fitted with nut and washer) is positioned to the side with the most access. Screw long bolt in completely until it bottoms out in the thread and starts to turn the eccentric crush tube.

Note: Both front and rear crush tubes must be equally adjusted and rotated to the same position.

- Re-connect ball-joint and tighten all hardware to manufacturers' 6. torque specifications.
- 7. Re-fit wheels, lower vehicle and settle suspension.
- 8. Test drive the car, check and re-tension all fittings.
- Check and adjust wheel alignment to desired settings. 9. To adjust, loosen lock-nut then short bolt and adjust by turning long bolt in clockwise direction only. Ensure both front and rear bushes are equally adjusted and rotated to the same position. Tighten in reverse order.
- 10. Check and re-tension all fittings again after 100kms but no more than 200kms.

Specifications:

Ccamber adjustment range: +/- 0.75 deg Above figures are indicative only. Actual adjustment range can vary depending on ride heiaht.

SUBFRAME MOUNT

SPRING SPRING WASHER CONTROL ARM NUT LONG BOLT SHORT (TURN BOLT CLOCKWISE) POLYURETHANE BUSH

- ECCENTRIC CRUSH TUBE Fig 3 - component assembly.



Fig 4 - right control arm, side view.

N.B: It is recommended that a licences workshop or tradesperson carry out tha above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.