

Fitting Instruction


Strut bar to Chassis Bushes

Holden Commodore

Suits: 1978- 9/97 VB-VS Sedan / Wagon / Ute

N.B: These instructions should be used in conjunction with workshop manual.

1. Raise the front of the vehicle and support on chassis stands.
2. Remove the front wheels from the vehicle.
3. Undo the front and rear nuts and washers from both ends of the strut bar and remove from the vehicle.
4. Remove old bushes from chassis end (front of strut bar) and discard.
5. Clean and remove any rubber deposits and inspect mounting point for damage, repair if necessary.
6. Lubricate end faces and internal bore only of the bushes with grease provided, before assembly.
7. Re-use original washers and nuts and refit new bushes to chassis making sure to fit them the correct way (refer diagram below).
8. Tighten all components to manufacturers recommended torque settings.
9. Carry out wheel alignment on vehicle .



NB: It is recommended that a licenced workshop or trades person carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.