

Instructions

Extension Brackets

- Swaybar and Head-light Sensor

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Page 1 of 2

Note - this kit can be installed at ride height or while lifted.

Application - Nissan Navara
- NP300

Always refer complete catalogue listing

Contents - 2x Link brackets
- 1x Head-light sensor bracket
- 2x M12 x 35mm bolt
- 1x M8 x 25mm bolt
- 2x Flat washers
- 2x Spring washers



- Un-bolt upper swaybar link nut.

- Using supplied brackets, M12 bolts and washers - bolt up bracket as per image.

- Place washers and nut on the inside.

- Bolt up original swaybar link to lower hole as per image.

RH side bracket shown



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

Instructions

Extension Brackets

- Swaybar and Head-light Sensor

Page 2 of 2

Continued;

Application - Nissan Navara
- NP300

Always refer complete catalogue listing

Contents - 2x Link brackets
- 1x Head-light sensor bracket
- 2x M12 x 35mm bolt
- 1x M8 x 25mm bolt
- 2x Flat washers
- 2x Spring washers

- Un-bolt original head-light bracket.

Discard bracket but retain original bolt.

Note - supplied bracket has 2 holes.
- upper hole suited for 2 inch lifted.
- lower hole suited for OE height.



- Bolt up new supplied bracket as per image.

Use supplied M8 bolt.



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.