

Instruction Sheet

Front Lower Shock Bushings

Z6061

N.B: This instruction sheet should be used in conjunction with the workshop manual

Note - these bushings are to suit a 35mm shock bush eye

Application - Mitsubishi Triton ML MN
- Mitsubishi Challenger PB

1. Raise vehicle evenly and safely support.

Never rely on a Jack only

(Always refer current catalogue for complete listings)

2. Remove front wheels and proceed to un-bolt upper control arm via ball joint bolts and inner bushing bolts.

Contents - Shell bushing 92028 x2
- Steel tube 19 x 14.3 x 48 x2
- Grease

Caution - the upper arm will be resting on the rubber droop stop. You may wish to lift/jack the lower arm up an inch or so.

3. Remove lower shock bushing bolt and proceed to un-bolt the 3 upper strut top nuts.

A hydraulic Press will be required to press out the lower bushing.

4. Proceed to press out old bushing including steel outer shell.

5. Press in new shell bushing.

6. Grease bushing internal diameter with supplied grease only.

7. Push in supplied steel tube.

8. Re-assemble vehicle.

Upper strut mount bolts



Ball joint bolts

Shock bushing

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.