

Fitting Instructions

Control Arm Bushes

1. Support the vehicle and disconnect the ball joint and sway bar link and remove wishbone.
2. Remove rubber from the original bush taking care not to damage or remove shell from arm. Clean all the rubber residue from inside the shell and lightly clean with emery or abrasive tape.
3. Insert bush into the shell making certain the large end of the bush is located against the flange on the shell. Lubricate bore of bush and fit the crush tube.
4. Lubricate end faces of bush and reinstall wishbone as recommended in the workshop manual.

NOTE: DO NOT REMOVE SHELL FROM ARM.

NOTE: IT IS RECOMMENDED THAT THE ABOVE PROCEDURE IS CARRIED OUT BY A LICENCED WORKSHOP OR TRADESPERSON

Fitting Instructions

Control Arm Bushes

1. Support the vehicle and disconnect the ball joint and sway bar link and remove wishbone.
2. Remove rubber from the original bush taking care not to damage or remove shell from arm. Clean all the rubber residue from inside the shell and lightly clean with emery or abrasive tape.
3. Insert bush into the shell making certain the large end of the bush is located against the flange on the shell. Lubricate bore of bush and fit the crush tube.
4. Lubricate end faces of bush and reinstall wishbone as recommended in the workshop manual.

NOTE: DO NOT REMOVE SHELL FROM ARM.

NOTE: IT IS RECOMMENDED THAT THE ABOVE PROCEDURE IS CARRIED OUT BY A LICENCED WORKSHOP OR TRADESPERSON