

2

Swaybar Mounts & Additional Options Page

Nolathane
Superior Suspension Systems

Part No: EVOCOM5F
Suits: VT-VZ COMMODORE

Year: 9/97-on
Cyl: 6 & V8



VEHICLE ENHANCEMENT KIT - FRONT

KIT CONTENTS

F or R	Description	Part No.	Kits Req	# of Bush	Notes
F	Control arm - lower inner	45318	1	6	Urethane only design - refer 45011A for steel shell design
F	Strut - mount standard	44019	1	2	Contains new bearings
F	Strut bar - to chassis (caster adj)	48166	1	2	Caster adjustment
F	Strut bar - to control arm	48019	1	4	
F	Sway bar - link	42449	1	8	Suits VT models

SWAYBAR LISTINGS

Please use the following listing to determine the correct swaybar bushes for your vehicle and fill in the accompanying form.

F or R	Description	Part No.	Kits Req	# of Bush	Notes
F	Sway bar - mount 24mm	42052	1	2	Suits V8 & susp. pack models
F	Sway bar - mount 26mm	42053	1	2	Suits V6 & SS pack models
F	Sway bar - mount 27mm	42054	1	2	

ADDITIONAL OPTIONS

Below is a list of all other kit Nolathane makes for your vehicle. Please see your nearest Nolathane reseller for the following additional options.

F or R	Description	Part No.	Kits Req	# of Bush	Notes
F	Evolution coilover - strut assembly	44900	1	2	Suits roaduse, complete pair of adjustable coilover struts
F	Evolution coilover - strut assembly	44900S	1	2	Suits superlow/showcar, complete pair of adjustable coilover struts
F	Control arm - lower inner	45011A	1	2	Steel shell design
F	Steering - rack mount	41105	1	1	
F	Strut - mount standard	44018	1	2	Re-use original bearings
F	Strut bar - complete rod only (new)	48900	2	1	Complete single strut bar only - suits LH or RH - bushes not incl.
F	Strut brace - adj polished alloy	44403A	1	1	(44403 s/seded)
F	Sway bar - link upper	42451	1	4	Suits VX -on models
F	Sway bar - link replacement kit	42997	1	8	Comp kit incl. h/duty link rods, nuts, washers & bushes
F	Sway bar - link ball/bush style	42708	1	2	Ball joint lower mount, bushes upper mount style link
R	Coil spring - seat lower (+6mm)	47307	1	2	Ride height increase
R	Coil spring - seat lower (+10mm)	47308	1	2	Ride height increase
R	Control arm - camber/toe adjust kit	46138A	1	4	FE2 or lower req 2 kits (46138 s/seded)
R	Control arm - camber/toe replacement	46139A	1	4	Bush replacement kit to suits 46138A only (46139 s/seded)
R	Control arm - inner & outer std replace.	46023	2	4	Only 1 kit req if used with 46138A Fit to outer only with multi link susp
R	Crossmember - mount outer	49008	1	4	Suits VT models reduces axle tramp
R	Crossmember - mount outer	49145	1	4	Suits VX models reduces axle tramp
R	Shock absorber - lower	43002	1	2	Suits wagon
R	Shock absorber - upper	43052	1	4	Suits wagon
R	Shock absorber - upper	43084	1	4	Suits sedan
R	Sway bar - link	42174	2	2	
R	Sway bar - mount 14mm	42039	1	2	O.E bush without flanges
R	Sway bar - mount 14mm	42036	1	2	O.E bush with flanges
R	Sway bar - mount 16mm	42037	1	2	O.E bush with flanges
R	Sway bar - mount 19mm	42169	1	2	O.E bush without flanges

Nolathane
Superior Suspension Systems

