

RMX Series Roof Racks

MAZDA 323 Astina Sedan 08/94 - 08/98 CARRYING CAPACITY


PART No:

RMX098

Rubber Mallet

80 kg

Safety Knife



Phillips Head Screwdriver

BOLT COVER

ASSEMBLY OF CROSS-BARS

- 1. Ensure the roof is clean, free from dust and grease.
- 2. Insert the neck of the End-Support into the void of the Cross-bar profile. They are designed to be a tight fit: use a rubber mallet if necessary (Fig.1)

ALLEN KEY

3. Pull back the rubber Buffer Strip about 20mm until the screw hole can be accessed.(Fig. 2) Using a Phillips Head Screwdriver, fasten the screw through the cross-bar and into the End Support.

Do this for all four sides and replace the buffer strip.

NOTE: The longer cross-bars are to be fitted to the front of the vehicle. Check labelling on the underside of the cross-bar.

FITTING CROSS-BARS TO VEHICLE


- 4. Anchor points are located on the vehicle roof trim strip. Unclip the four covers to reveal the built in roof bar anchorage points.
- Keep the covers, along with the rola key in your glove box for replacing when the roof bars are removed. To clean debris from the screw threads, fit and the remove the special bolts into each anchor point to proceeding.
- 5. Position the rubber pads over the anchor points. Place the crossbar assemblies onto the pads and partially engage the special bolts into each anchor point. After any minor re-alignment, tension up both sides equally with the rola security key provided.
- 6. Gradually tighten bolts alternately until even tensioning is achieved. A firm hand tightness is adequate for correct tension.

DO NOT overtighten Special Bolts as this may result in roof damage.

Please Note: If the bolts are fully tightened and there is still thread exposed you may need to fit the bolts with a spring washer and flat washer under the bolt head. This places greater force on the end support correcting any issues caused by vehicle variances.

- 7. Proceed to follow steps 4 to 6 when mounting the Rear Cross-bar Assy.
- 8. You are now ready to mount your "Accessories" set onto the cross-bars using the Global Mount Channel. Once installed, insert the 'Global Channel' Covers into the End Supports.

NOTE: You have a choice of 2 - (a) quick access snap-on cover or (b) long term mounting - security cover to cap off and lock the mount channel. (Fig. 6)



General Usage Information

It is essential for the proper assembly, operation and use of the Roof Rack that the instructions and safety precautions supplied are strictly observed. Read any fitting, care and usage instruction carefully.

The maximum permissible load for your Roof Bar is the lower of the maximum load capacity specified in your vehicle operation manual, or specified as applying to the Roof-Rack. Do not exceed the maximum specified load capacity.

Maximum permissible load = weight of the Roof Rack + weight of accessories + weight of load (cargo).

When fitting the Roof-Rack and transporting a load, ensure the vehicle's functions are not impaired (eg, sunroof, aerials, windscreen wipers, mirrors). Rear doors on Hatch- and Wagon-type vehicles should be inspected for adequate clearance for full opening operation of the boot/tailgate.

Stop and check all screw connections, bolts and retaining straps after a short distance of travel. Repeat these checks at regular intervals.

Warnings

Remember that the fitting of a Roof Rack and the transport of a load increases the overall height of the carrying vehicle.

Where the Roof-Rack is to be used in off-road conditions, a safety weight reduction of 1.5 should be observed from the total carrying capacity. (eg. 60kg becomes 40kg)

Cequent will not be liable to the purchaser or any other person for any consequential, incidental, direct or indirect loss, damage or costs incurred of suffered by the purchaser or any other person including but not limited to damage to persons or property, loss of turnover, loss of profits, loss of business or goodwill, arising from or in relation to the assembly and use of the Roof rack, or the non-observance of the fitting and care instructions.

APPENDICES & ADDITIONAL 'FITMENT SPECIFIC' FITTING STEPS - IF REQUIRED

This area has been intentionally left blank.