

# LOW MOUNT

Toyota LandCruiser 300 series

LRS032-FI Revision B, September 2025

## PACK CONTENTS & FITTING INSTRUCTIONS



M8 DROP-&-TURN BOLT (22-0924) x12



LOW MOUNT WITH END CAPS x6 (25-0310 - 2 pack) Each Low Mount contains two end caps



M8 FLAT WASHER (22-0195)



TOP STRAP



M8 SPRING WASHER (22-0162)



LOWER STRAP



M8 HEX NUT (22-0139)



M8 T BOLT 22-0961



M8 X 35 BOLT 22-0968



INTERCONNECTING BLOCK (25-0368) x3 for TFT31212, TFT31512, TFT31812, TFT32012 x4 for TFT31514, TFT2014



(32-0050) x3


**NOTE:** Fasteners supplied with Titan Tray are required for this fitment.




Read instructions thoroughly before commencing installation.

Refer to Titan Tray instructions for tray assembly.

Skip to Step 5 on the following page if you have already inserted the interconnecting blocks.



Refer to Titan Tray Instructions. Remove the end plank of the tray.



# For TFT31212, TFT31512, TFT31812 & TFT32012:


Insert the three interconnecting blocks between the four centre planks.

Position interconnecting blocks in the centre of the tray.

### For TFT31514, TFT32014:

Insert the four interconnecting blocks between the five centre planks.


Position interconnecting blocks in the centre of the tray.





## **LOW MOUNT**


## FITTING INSTRUCTIONS CONTINUED


# ROLA























### **LOW MOUNT**


### FITTING INSTRUCTIONS CONTINUED














### **USAGE INSTRUCTIONS**

It is essential for the proper assembly, operation and use of the roof-rack that the instructions and safety precautions supplied are strictly observed. The maximum permissible load for your roof rack or tray is the lower of the maximum load capacity specified in your vehicle operation manual, or specified as applying to the roof-rack or tray. Do not exceed the maximum specified load capacity.

 $Maximum\ permissible\ load = weight\ of\ the\ roof-rack\ and\ tray + weight\ of\ accessories + weight\ of\ cargo\ load.$ 

When fitting the roof-rack and transporting a load, ensure the vehicle's functions are not impaired (e.g. sunroof, aerials, windscreen wipers, mirrors). Hatch and wagon vehicles should be inspected for adequate clearance for full opening operation of the boot/tailgate.

 $Stop\ and\ check\ all\ screw\ connections,\ bolts\ and\ retaining\ straps\ after\ a\ short\ distance\ of\ travel.\ Repeat\ these\ checks\ at\ regular\ intervals.$ 

### WARNINGS

Remember that the fitting of a roof-rack and the transport of a load increases the overall height of the carrying vehicle.

Where the roof-rack is to be used in off-road conditions, a safety weight reduction of 1.5 should be observed from the total carrying capacity (e.g. 60kg becomes 40kg).

Cequent will not be liable to the purchaser or any other person for any consequential, direct or indirect loss, damage or costs incurred or suffered by the purchaser or any other person including but not limited to damage to persons or property, loss of turnover, loss of profits, loss of business or goodwill arising from or in relation to the assembly or use of the roof-rack, or the non-observance of the fitting and care instructions.