

## CONTROL ARM BUSHES

1. Support the vehicle and disconnect the ball joint
2. Remove control arm
3. Press out old bushings from both eyes in arm.
4. Before fitting new bushes, install original washers against shoulders at each end of pivot pin.
5. Fit shelled bush to eye in arm and press to swage mark on bush shank. When pressing bush into arm, take care to support the arm around each eye to avoid damage to arm.
6. Before assembly, lubricate end faces on bush with grease provided in kit.
7. Refit end washers and tighten locknuts after installation. Reassemble suspension as recommended in the workshop manual.
8. Tighten all components to manufacturers' recommended torque settings

