

**Note:** This bar replaces original trailing arm type mounted bar.

1. Place the U-bolts over the differential making sure that the brake lines are clear. Using the 10mm plates, D-bushes and saddles attach the bar to the differential (as shown in illustration). Do not tighten nuts at this stage.

2. Assemble links to box section (use large hole) and swaybar as shown in diagram.

3. Lift link up to the trailing arm & chassis mounts, Ensure that the links are vertical, note that the "U" bolt assembly is to be mounted back from centre line of differential.

Also ensure swaybar is centrally located between trailing arms. Mark position for bolts to chassis, swing bar out of way, drill 10mm hole. Bolt assembly up.

**Caution:** Do not over tighten link nuts and do not tighten nuts to a point of where the link rubbers are distaughted.

