



Instructions Front Transmission Mount - Insert

NOTE: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Application - Toyota Yaris GR
- AWD Turbo

Always refer complete catalogue listing

Contents - 1x Poly Insert 69231 x2

WHITELINE Performance insert is designed to reduce engine movement during acceleration and gear changing, resulting in sharper gear changes and better power delivery to the wheels

- Raise vehicle evenly and safely support.

Never rely on a Jack only

- Proceed to un-bolt the Pitch-stop mount
Refer images below.



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

Instructions

Front Transmission Mount - Insert

NOTE: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Note - moderate NVH increase may be noticed in cabin



- Note the voids in the OE rubber mount.

The Insert 'fingers' are to be pushed into OE voids.



- Firmly push insert into position. Push all the way until it stops.
- Re-fit mount to vehicle using original bolts.
- Tighten front bolts to 60Nm
Tighten large rear bolt to 110Nm

Road test and re-check all bolts after 200kms travelled.

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.