

Fitting Instructions #2831IS

Jeep

Rear Sway-bar Link Kits



These kits require the fitting of a washer to the mounting pin during assembly as per below.

- Remove the original link(s) from the vehicle;
- Use a hand/arbour press and push out the original bushings;
- Clean the inside of each end of the link(s) removing any remaining rudder from inside the housing;
- Using grease supplied, grease inside of housing, outside of bushing and install new bushing into the housing. Grease new steel tube and install in bushing;
- Assemble the link(s) to the vehicle installing new washer as per drawing below;
- Tighten all mounting bolts and nuts to the manufacturer's specifications.

Lower Bushing - Right Hand Side

