

Fitting Instructions #1986IS

Mazda MX5

Control Arm Upper Inner Kit

- Jack vehicle and put on stands/hoist following manufacturer's recommendations remove front upper control arm.
- Using suitable press tools remove old bushes being careful not to damage the arm.
- Apply the supplied grease on the internal diameter of the housing of the arm and the outer surface of the bush.
- Using the picture below as a guide insert the bushing into the arm note the larger flange goes to the outside of the arm.
- Grease the bore of the bush and insert the supplied crush tube.
- When reinstalling arm note that the newly supplied washers should go to the inboard position of the arm as shown below.
- All other washers are to be re-used in their original positions.
- Refit upper control arm to vehicle tighten all bolts to manufacturers torque settings and wheel align vehicle
- *Note:* Polyurethane bushings must be fitted to both sides of the vehicle

