

Fitting Instructions #2062IS

Mitsubishi Evo 4, 5, 6, 7, 8 & 9

Control Arm Upper-Inner Front Bushing

Kit Contents:

- 2 x Polyurethane Bushings (2062);
- 2 x Steel Mounting Pins.

Remove the Original Equipment (OE) bushings:

Once the arm is removed from the vehicle, the OE bushings should be pressed out of the cast alloy arm with a hydraulic press. Care must be taken to avoid damaging the arm.

Install the polyurethane replacement bushings:

Wherever polyurethane and metal make contact, use the grease supplied to generously lubricate both surfaces.

Important areas are:

- Inside the control arm housing;
- The mounting pin centre section;
- The bushing bore.

Push the polyurethane bushing into the arm, then the mounting pin into the bushing.

Reassemble the arm into the vehicle and torque to manufacture's specifications.