

# Fitting Instructions #4608IS

Nissan Navara

## Front Upper Control Arm Bushing

**Note:** Polyurethane bushings must be fitted to both sides of the.

- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands/hoist;
- Remove the upper control arms of the front suspension;
- Remove original bush with the use of a hydraulic press and suitable pressing tools;
- Apply the white grease supplied to outside surface and into the bore of the bush, and the outside of the crush tube;
- Push the new polyurethane bushing into the control arm housing, and then the tube into the bush, as shown in the Figure 01;

**\*Important:** Please note the thicker flange of the bush is oriented towards outside of the arms.

- Refit the control arm to the vehicle and tighten all bolts to manufacture's torque settings;
- Carry out wheel alignment.



Figure 01 - '4608' bush installation