

Fitting Instructions #TRC1218IS

VW Golf / Audi A3 S3

Adjustable Rear Control Arm (front arm)



Page 1 of 2

Superpro performance adjustable control arms are constructed of 6061-T6 alloy combined with 1020 forged ends. Bushings are of low compliance resulting in precise turn in and driver feedback during high corner speeds.

Contents - 2x live adjustable control arms
- 2x extra tubes 19x14.3x37mm

- Raise vehicle evenly and safely support.

Never rely on a jack only.

- Proceed to remove the original control arms.

Tip - remove swaybar bushing mount to gain better access to control arm.

Refer LH image



- Do not discard original washers and bolts
Refer RH image.



Refer page 2

It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

- Place new adjustable arm on top of original arm - using original bolts. This will determine a base line length pre wheel alignment. Refer RH image.

IMPORTANT - MK5 and MK6 vehicles will use the supplied 14mm ID tube for the bolt at hub. Refer below.



- Finish bolting up inner point as per below.

Tip - it may be easier to jack hub upwards 30-40mm to help with install.



- **IMPORTANT** - a wheel alignment will be required soon after install.
- Road test vehicle
- Re-check all bolts after 500kms

It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.