

Fitting Instructions #5801IS

Toyota – GR Corolla, GR Yaris

Front Transmission Mount Support Void Filler

Superpro
Suspension Parts

- Raise vehicle evenly and safely support;
Never rely on a jack only
- Proceed to un-bolt the Pitch-stop mount.
- Refer images below;

Note: This kit should be installed by a qualified motor mechanic



- Note the voids in the OE rubber mount.
The insert 'fingers' are to be pushed into the
OE voids



Fitting Instructions #5801IS

Toyota – GR Corolla, GR Yaris

Front Transmission Mount Support Void Filler

Superpro
Suspension Parts

- Firmly push insert into position.
Push all the way until it stops.



- Re-fit mount to vehicle using original bolts.
- Tighten front bolts to 60Nm.
- Tighten larger rear bolts to 110Nm.
- Road test and re-check all bolts after 200kms of travel.

Note - moderate NVH increase may be noticed in cabin