

Fitting Instructions #2777IS

Mitsubishi Pajero

Rear Lower Trailing Arm Front Bushing

Note: Polyurethane bushes must be fitted to both sides of the vehicle.

These Bushings are eccentric and care must be taken to time the bushes correctly in both arms



- Following manufacturers recommendations remove rear lower trailing arms from the vehicle;
- **Take note of the bushing orientation** some vehicles have the bush orientated towards the front as shown in the image above, towards the rear or central.
- Remove original bushings from the trailing arms with the use of a hydraulic press and suitable pressing tools;
- Taking into account your notes, align the bushing in the arm so that the hole in the bushing is orientated in the same position as it was originally

- If the original position is central time both bushes vertically
- Press the new bushing into the trailing arm



- Lubricate the inside of the new polyurethane bushing with the grease supplied and install the steel crush tube. Lubricate the side faces of the new bushings and the areas on the chassis that contact the new bushings;
- Refit the trailing arms with the new bushes & tubes into the vehicle. Tighten all fasteners to the manufacturer's