

# Fitting Instructions #4400IS

## Landrover Discovery 2

### Rear Watts Link Bushing Kit

- Jack vehicle and put on stands or support on hoist
- Remove the necessary components to gain access to the watts link bolts.
- Support the differential and remove the mounting bolts.
- Remove the OE bushes including the shell from the watts link by using a hydraulic press and suitable pressing tools.
- Clean housing areas to remove any old original bushing materials before installing new polyurethane bushes.
- Apply the grease supplied to all mating surfaces; push the new cotton reel **(1)** into place, push the crush tube **(2)** into the bush, insert the poly washer over the crush tube **(3)** and then, install the steel washer **(4)** onto the step of the crush tube (step no.4 is for 4402 only, not required for 4401).
- Refit all mounting bolts and torque to manufacturers specifications.
- Refit all other removed components.

