

# Fitting Instructions #1590BIS

## Holden Commodore VE

### Strut Top Bushing

---

- Jack the vehicle up and support on jack stands;
- Remove the struts;
- Remove original top strut bush with the use of suitable tools;
- Install the new polyurethane top strut bush with the original washers;

**Important Note:** the washers need to be orientated as it is shown in the picture below\*;

- Refit the strut to the vehicle and tighten all bolts to manufactures torque settings;
- Carry out a wheel alignment.

