Fitting Instructions #1217IS

Nissan Maxima, Pintara, Bluebird **Control Arm Lower-Front Bushing**



- Steel washers included in this kit **must be used** to resist movement under braking.
- Ensure that the grease supplied is used on all mating steel surfaces;
- Retighten all fasteners to the manufactures specified torque;
- Carry out wheel alignment check

