

Fitting Instructions #4896IS

Mitsubishi MQ Triton 2015-on

ABS Cable Bracket Extension Kit

Important Note: *These components must be fitted by qualified persons only, to factory specifications, as per factory service manual.*

This kit may be required when fitting long travel rear shocks to prevent ABS cables becoming overstretched.

Ensure there is enough slack in ABS cables at full droop to prevent damaging the ABS cables.

Installation Instructions:

Remove OE bolt holding ABS cable bracket to top of differential housing (see picture);

Fit tube between differential housing and ABS cable bracket (see diagram);

Put spring washer on supplied bolt, followed by flat washer and install bolt so the flat washer is against the top of the ABS cable bracket (see diagram);

Tighten supplied bolt to OE specifications;

