

Fitting Instructions – Z7044

Dodge Ram 1500

Sway Bar Bushing

KIT CONTENTS		
PART No.	DESCRIPTION	QTY
20155Z	Front Sway Bar Bush	2

Note, this instruction sheet should be used in conjunction with a workshop manual and proper safety procedures followed.

- Place the vehicle securely on a hoist or jack stands
- Remove sway bar bracket
- Remove OE rubber bushing by cutting a slit in one side of the bush and peeling the bush off, as seen below



- Apply grease to the bore of the new bushing
- Place new bushing over the sway bar
- Re-install the sway bar bush bracket, which should look as shown below

