

Fitting Instructions #2637IS

Nissan Silvia / Skyline

Rear Differential Pinion Mount Bushing



- Jack the vehicle up and support on jack stands;
- Remove the differential;
- Remove original shell/bush part from the housing with the use of a hydraulic press and suitable pressing tools or air chisel and deburr;
- Clean housing areas to remove any old original bushing materials before installing new bushes. Apply the grease supplied to the housing and the outside of the new bushes, and then push them in as shown in the picture;
- Apply the grease supplied to the bore of each bush and the outside of the crush tubes, then push in the crush tube as shown in the pictures;
- Refit the differential to the chassis using the new washer supplied, and tighten all bolts to manufacture's torque settings;
- Carry out a wheel alignment.

