

Fitting Instructions #5696IS

Holden Rodeo TFR 2WD (1988-2003)

Front Upper Control Arm Inner Bush Kit



Note: Polyurethane bushings must be fitted to both sides of the vehicle.

Contents: Bushing 5243 x4, washer 32x19x2mm x8, steel tube 22x18x45mm

- Wheel-align the vehicle before the job is started and note settings;
- With the vehicle on jack stands/hoist, remove the front upper control arms;
- With the use of a hydraulic press and suitable pressing tool, remove the factory bushes including the steel shell;
- Clean housing areas to remove any old original bushing materials;

NOTE – Push supplied washer on (2x per side to seat against inside bushing face).

- Using the appropriate pressing tools support the control arm and press in the new bushes according to the orientation shown in figure below;
- Ensure to apply the supplied grease onto all mating surfaces;
- Refit the front upper control arms to the vehicle and tighten the bolts;
- Ensure that all fasteners are torque to manufacturer's specification and carry out a wheel alignment.

