

Fitting Instructions #1225IS

Jeep Wrangler

Sway Bar Link Bushing Kit



This kit requires the fitting of a washer to the mounting pin during assembly as per below.

- Remove the original link for the vehicle;
- Use a hand press and push out the original bushings;
- Clean the inside of each end of the link clean any remaining rubber from inside the housing;
- Using grease supplied, Grease inside of housing, grease outside of bushing and install new bushing into the housing. Grease new steel tube and install in bushing;
- Assemble the link to the vehicle installing new washer as per drawing below.

Note: Tighten all mounting bolts and nuts to the manufacturers specifications.

