

Fitting Instructions #4262IS

Honda Jazz / City / Fit

Front Control Arm Lower Front Bushing



Note: Polyurethane bushings must be fitted to both sides of the vehicle.

- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands/hoist;
- Remove the lower control arms;
- Remove original shell parts from the housing with the use of a hydraulic press and suitable pressing tools;
- Using the grease supplied, lubricate the housing and outside diameter of the new bush and push it into the lower control arm front housing;
- Generously lubricate the outside of the steel tube and inside of the bush, then push the steel crush tube into the bush;
- Refit the control arms to the vehicle and tighten all bolts to manufacture's torque settings;
- Carry out wheel alignment.

