

# Fitting Instructions #3201IS

Subaru WRX

## Differential Support Bracket Mount Kit (Rear)



**Note:** Polyurethane bushings must be fitted in both sides of the vehicle at the same time.

- With the vehicle on jack stands, remove the differential mount bolts. Refer to your workshop manual for detailed instructions of how to remove them from the vehicle;
- Remove the original bushes, including the shell, by using a hacksaw to cut through the shell and prize out;
- Ensure that the grease supplied is used on all mating surfaces during assembly and install the bushes, with the orientation as it is shown in the picture to the right.
- Use threaded rod and suitable sized rings to pull the bushes into place;
- Apply the grease supplied to the bore of the bush and the steel crush tube. Push in the crush tube;
- Refit the diff bolts;
- Ensure that all bolts are tightened to the manufactures specifications then proceed to have the vehicle wheel-aligned.

