

Fitting Instructions #3762IS

Mazda BT50 Fifth Generation

Sway Bar Link Pin Bush Kit

- Fitting instructions for fitting Mazda BT50 Link Bushings.
- Remove old OE bushes as per manufactures instructions.
- Clean up original link pin.
- Grease and reassemble with new bushes noting the orientation of the cupped washers. These are to be fitted in the inverted position as per photo. This allows for less restricted movement of the bushing.
-
- The link is to be tightened only as far as the photo shows- only one thread is showing above the nut.
- Over tightening will cause the bushings to fail.

