

Fitting Instructions #3818IS

Toyota 86 / Subaru BRZ

Sub Frame to Body Mount Bushing

- Jack vehicle up and put on stands/hoist, remove rear wheels, exhaust pipe and the control arms/trailing arms that are attached to the sub frame;
- Remove the sub-frame and place it on separate jack stands then proceed to remove factory bushes;
- Clean housing areas to remove any old original bushing materials before installing new bushes. Also, remove the OE washer from the upper front position***;
- Apply the grease supplied to the housing and the outside of the bush, then push the new bushes in with reference to the diagram;
- To fit the crush tube into the bushes, apply the grease supplied to the bore of the bush and the outside of the crush tube and then, push it in. Use a pair of multi grips to aid installation of the crush tubes;
- Repeat process to install the rest of the bush;
- Refit the rear sub-frame and all other suspension member to the vehicle ensuring that you use manufacturer's

