

# Fitting Instructions #0601-SLIS

Holden Commodore

*Rear Bump Stop Kit*

---



The original foam insert Bump Stop must not be fitted to the new design SUPER LOW Bump Stop. To obtain the optimum Ride, Comfort and Load Carrying capacity the foam must be left out.

# Fitting Instructions #0601-SLIS

Holden Commodore

*Rear Bump Stop Kit*

---



The original foam insert Bump Stop must not be fitted to the new design SUPER LOW Bump Stop. To obtain the optimum Ride, Comfort and Load Carrying capacity the foam must be left out.

# Fitting Instructions #0601-SLIS

Holden Commodore

*Rear Bump Stop Kit*

---



The original foam insert Bump Stop must not be fitted to the new design SUPER LOW Bump Stop. To obtain the optimum Ride, Comfort and Load Carrying capacity the foam must be left out.

# Fitting Instructions #0601-SLIS

Holden Commodore

*Rear Bump Stop Kit*

---



The original foam insert Bump Stop must not be fitted to the new design SUPER LOW Bump Stop. To obtain the optimum Ride, Comfort and Load Carrying capacity the foam must be left out.