

Fitting Instructions #1987IS

Mazda MX5 / Eunos Roadster

Sway Bar to lower control arm link bushes



Two metal washers are included in this kit.

These washers are to be used on the upper end of the links to captivate the polyurethane cotton-reel.

They should be fitted on the opposite side of the cotton-reel to the sway bar end, with the cupped profile facing away from the polyurethane bush.

Fitting Instructions #1987IS

Mazda MX5 / Eunos Roadster

Sway Bar to lower control arm link bushes



Two metal washers are included in this kit.

These washers are to be used on the upper end of the links to captivate the polyurethane cotton-reel.

They should be fitted on the opposite side of the cotton-reel to the sway bar end, with the cupped profile facing away from the polyurethane bush.