

Fitting Instructions #2575IS

Volkswagen / Audi / Skoda / Seat

Engine Support Lower Front - Poly Insert Bushing



This kit includes 2 washers, to maintain support for the new "Insert" bushings these are to be fitted as shown in photo at the bottom of this instruction sheet.

- Remove the bracket from the vehicle;
- Hold the aluminium bracket in a vice, taking care not to damage the bracket. Using a flat blade screwdriver, pry between the bracket and the original bushing to remove the outer support bracket from the centre of the original bushing;
- With the outer support bracket removed push the 2 new "Inserts" into the voids in the original bushing;
- Re-fit the outer support bracket to the centre of the original bushing;
- Install bracket with the inserts fitted, back on to the vehicle installing the washers in the positions as shown below.

