

Fitting Instructions #3497IS

Honda Accord Euro

Subframe to Chassis Mount Bushing

- Support vehicle on jack stands/hoist;
- Support the rear of the sub frame with a jack/axle stand and loosen the rear sub frame bolts;
- Lower sub frame until there is enough clearance to remove the OE upper bush and install the new '3497' SuperPro bush. Also make sure no wires or lines are stretched;
- **Suggestion:** once the subframe is lowered, don't remove all bolts at once, but remove only one bolt completely first, replace the OE bush by the new '3497' bush on that position and install the removed bolt again, and then repeat the same procedure one by one until all four bushes are replaced;

Note: the steel washer bonded to the blue polyurethane of the '3497' bush should be facing the vehicle body.

- Tighten all the subframe bolts, shock absorber bolts and control arm bolts to the manufacture's torque settings;
- Carry out a wheel alignment.

