

Fitting Instructions #3915IS

Toyota 86 / Subaru BRZ, Forester, Impreza, WRX
Rear Sway Bar Link Complete Rod Replacement



- Jack vehicle up and put on stands/hoist, following manufacturer's recommendations, unbolt and remove the sway bar links;
- Clean the control arm areas where the link sits;
- Release lower shock absorber bolt to relieve tension on control arm;
- Install the new sway bar link to the vehicle ensuring that you use manufacturer's torque settings on all fasteners;
- Re-torque lower shock absorber bolt at vehicle ride height.



Fitting Instructions #3915IS

Toyota 86 / Subaru BRZ, Forester, Impreza, WRX
Rear Sway Bar Link Complete Rod Replacement



- Jack vehicle up and put on stands/hoist, following manufacturer's recommendations, unbolt and remove the sway bar links;
- Clean the control arm areas where the link sits;
- Release lower shock absorber bolt to relieve tension on control arm;
- Install the new sway bar link to the vehicle ensuring that you use manufacturer's torque settings on all fasteners;
- Re-torque lower shock absorber bolt at vehicle ride height.

