


Fitting Instructions #4358IS


LEXUS IS GSE2_, ALE2_, USE2_ / LEXUS IS F USE2_

Front Lower Control Arm Front Bushing



Note: Polyurethane bushes must be fitted to both sides of the vehicle.

- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands/hoist;
- Using factory manual, remove the front lower control arms;
- Remove original shell parts from the housing with the use of a hydraulic press and suitable pressing tools;
- Grease up the body of the bush and the inside of the housing, then, press the bushes into the housing;



- Liberally apply the grease supplied to the polyurethane bore of the bush, the outside of the steel crush tubes. Then, press the steel crush tubes into the bushes. An arbour press may be required to insert the steel tube.
- Refit the front lower control arm to the vehicle and tighten all bolts to manufacture's torque settings and carry out a wheel alignment.